



Installing LG L1200 SIM Card



Step 1 - SIM Card

- Remove the battery from the back of the phone by lifting up the tab.



Step 2

- Push the SIM Card up using your thumb until it is removed.



Step 3

- Once removed, replace with new SIM Card, making sure that the cut corner fits into the cut corner of the slot.